





SHEAR STRESSES



$$\int_A \tau_{xy} dA = -V$$



$$\int_A y \sigma_{xx} dy = -M$$



$$\int_{A'} (\sigma_{xx} + \Delta\sigma_{xx}) dA' - \int_{A'} \sigma_{xx} dA' = \tau_{yx} \tau \Delta x$$

$$\Rightarrow \int_{A'} \Delta\sigma_{xx} dA' = \tau_{yx} \tau \Delta x$$

$$\Rightarrow \tau_{yx} \tau = \int_{A'} \frac{\Delta\sigma_{xx}}{\Delta x} dA' \xrightarrow{\Delta x \rightarrow 0} \int_A \frac{d\sigma_{xx}}{dx} dA'$$


$$\begin{aligned}
 \tau_{yx} z &= \int_{A'} \frac{d}{dx} \left(\frac{-M y}{I} \right) dA' = - \int_{A'} \frac{y}{I} \frac{dM}{dx} dA' \\
 &= - \int_{A'} \frac{V y}{I} dA' \\
 &= - \frac{V}{I} \int y dA'
 \end{aligned}$$

$$\therefore \boxed{\tau_{yx} = - \frac{V Q}{I z}} \quad \left[Q = \int y dA' \right]$$

Shear stress formula

↳ 1st moment of area of the part of the c/s under consideration

$$\tau_{xy} = \tau_{yx} = - \frac{V Q}{I z}$$




$$t = b; \quad I = \frac{1}{12} b h^3$$

$$Q = b \left(\frac{h}{2} - y \right) \left(y + \frac{1}{2} \left(\frac{h}{2} - y \right) \right)$$

$$= \frac{1}{2} b \left(\frac{h^2}{4} - y^2 \right)$$

$$\tau_{xy} = - \frac{VQ}{Iz} = \frac{-V}{\frac{1}{12} b h^3 b} \cdot \frac{1}{2} b \left(\frac{h^2}{4} - y^2 \right)$$

$$= - \frac{6V}{bh^3} \left(\frac{h^2}{4} - y^2 \right)$$




$$\text{max} \rightarrow \tau_{xy}|_{y=0} = \frac{-6V}{bh^3} \frac{h}{4} = \frac{-3V}{2bh} = -\frac{3}{2} \left(\frac{V}{bh} \right)$$

$$\frac{V}{bh} : \tau_{avg}$$


$$\tau_{max} = \frac{3}{2} \tau_{avg}$$




$$\text{min} \rightarrow \tau_{xy}|_{y=\pm \frac{h}{2}} = 0$$





$$|\tau_{xy}| = \frac{6|V|}{bh^3} \left(\frac{h^2}{4} - y^2 \right)$$

valid along z direction if $\left(\frac{b}{h} < \frac{1}{4} \right)$





Shear flow (along length)




built-up beam

$$\tau_{yx} = - \frac{VQ}{It}$$



$$\Rightarrow \underbrace{(\tau_{yx} t)}_{\substack{\text{Force per} \\ \text{unit length}}} = - \frac{VQ}{I}$$

↓
shear flow



$$\underbrace{(\tau_{zx} t)}_{\text{shear flow}} = \frac{VQ}{I}$$

Shear flow distribution (within a c/s)



$$\int_{A'} (\sigma_{xx} + \Delta\sigma_{xx}) dA' + \tau_{zx} \tau \Delta x = \int_{A'} \sigma_{xx} dA'$$

$$\Rightarrow \tau_{zx} \tau \Delta x = - \int_{A'} \Delta\sigma_{xx} dA'$$

$$\Rightarrow \tau_{zx} \tau = - \int_{A'} \frac{\Delta\sigma_{xx}}{\Delta x} dA' \rightarrow - \int_{A'} \frac{d\sigma_{xx}}{dx} dA'$$

EXTREMELY
IMPORTANT!
Walls must be thin

$$\begin{aligned} \Rightarrow \underbrace{\tau_{zx}}_{\text{Shear flow } q} &= - \int_{A'} \frac{d}{dx} \left(- \frac{My}{I} \right) dA' \\ &= \int_{A'} \frac{dM}{dx} \frac{y}{I} dA' \\ &= \frac{V}{I} \int_{A'} y dA' \\ \text{Shear flow } q &= \frac{VQ}{I} \end{aligned}$$

Shear flow associated with τ_{xz} is going to be equal to that associated with τ_{zx} , i.e. $\frac{VQ}{I}$

